

Airborne Emission Spectrometer

David Rider
Jet Propulsion Laboratory, *Calif. Inst. of Tech.*
4800 Oak Grove Dr.
Pasadena, CA 91109
Phone: (818) 354-3776
Fax: (818) 393-4619

Reinhard Beer
Jet Propulsion Laboratory
4800 Oak Grove Drive
Pasadena, CA 91109
Phone: (818) 354-4748
Fax: (818) 393-4445

And

Helen Worden
Jet Propulsion Laboratory
4800 Oak Grove Drive
Pasadena, CA 91109
Phone: (818) 354-4748
Fax: (818) 393-4965

The Airborne Emission Spectrometer (AES) is a Fourier transform spectrometer designed for remote sounding of the troposphere from an aircraft platform. The instrument covers the 650 cm^{-1} to 4350 cm^{-1} spectral range with a resolution of better than 0.1 cm^{-1} . The primary focus of AES investigations is to study the distribution of tropospheric ozone and the factors controlling the formation and distribution of tropospheric ozone. **How'ever, having access to a wide variety of atmospheric constituents, the instrument has proven to be useful in several remote sensing applications. The instrument has been deployed on NASA's DC-8, P-3B and C-17@ aircraft, collect ing infrared spectra over a wide range of targets and atmospheric conditions.**

The optical layout of the instrument is illustrated in Fig. 1. The spectral range of the instrument is covered with 4 channels. **each** optimized for a 300 cm^{-1} to 525 cm^{-1} interval. Dichroic reflectors **together with a cold, remotely selectable, bandpass filter define each of the four channels. The three highest frequency channels use photovoltaic HgCdTe linear array detectors. The lowest frequency channel uses a photoconductive HgCdTe linear may. All arrays have 4 elements with each element viewing a solid angle 01.1 $\text{mr} \times 8 \text{ mr. , All detectors arc operated at 65 K.$**

The Michelson interferometer employs cube corner reflectors **anti a Ge coated KBr beam splitter. The moving cube corner, driven with a lead screw and high torque motor, travels $\pm 5 \text{ cm}$ about zero path difference every 3 s. Signals are digitized over a 2 s interval nominally centered on the zero path difference. A diode pumped Nd:YAG laser directed down the center of the interferometer optical path provides fringes used to generate the interferogram sampling clock.**

The detectors **view** the scene through the interferometer with a 2.9 $f/\#$ system. **A two axis gimbaled pointing mirror together with a gyro-stabilized pointing control system provides image motion compensation insuring a stable scene while interferograms are recorded. The instrument also includes an edge/centroid video tracking system that permits the instrument to lock onto a target in the scene if desired. The gimbaled mirror also 'it'ws a blackbody for radiometric calibration of the spectrometer.**




Figure 1. Airborne Emission Spectrometer optical layout.




Figure 2. AES spectrum recorded over a forested area from an altitude of 6 km. This spectral region contains contributions from CO₂, O₃, N₂O and 1 H₂O.

The **16 detector signals** are conditioned, bandpass filtered and digitized in an **electronics module mounted on the dewars**. The digitized **signals** are collected by a **PC based instrument control system** and stored **on an 8 mm tape**. **Data processing is done off-line**. The raw interferograms and engineering data **are first** put into a standard format to **facilitate archiving**. The individual interferograms **are then** phase corrected and transformed to spectra using standard Fourier transform techniques. Raw **spectra are** converted to **radiances using calibration blackbody views** and a **linear relationship between instrument signals and radiance**.

The detector dewars, interferometer and **pointing mirror** are mounted on a common optical bench that is isolated from the aircraft with pneumatic shock mounts. The mounts provide excellent vibration **isolation at** frequencies above 10 Hz.

An example of a **spectrum in the 950 cm^{-1} to 1200 cm^{-1} range recorded with the instrument at an altitude of 6 km is shown in Fig 2**. This **region is particularly useful for** measurements of tropospheric ozone and also contains spectral features of CO_2 , N_2O and 1120.

The **paper will describe the instrument** and its performance, and summarize recent results of field measurements.