

# AEGIS Autonomous Targeting for ChemCam: Protecting the Rover and the Instrument




Risk-Aware Machine Learning Workshop – 21 April 2017

Raymond Francis, PhD

Machine Learning and Instrument Autonomy Group

**Jet Propulsion Laboratory**  
California Institute of Technology



# ChemCam Instrument

on the Curiosity rover

- Laser-Induced Breakdown Spectrometer (LIBS) with Remote Micro-Imager (RMI)
- Gives geochemical composition of rock targets at ranges up to 7 metres
- Over 440,000 measurements on 1500 targets on Mars since 2012
- Targets selected by specialists on Earth, inspecting images returned from Mars
- Joint development of
  - Los Alamos National Laboratory (LANL, Los Alamos)
  - Institut de Recherche en Astrophysique et Planétologie (IRAP, Toulouse)



# AEGIS Intelligent Targeting System

**"Automated Exploration Gathering Increased Science"**


**AEGIS was first flown on MER Opportunity in 2010**

- Autonomous target selection for PanCam (mid- or post-drive)


**Now in use for ChemCam on MSL, in two roles**

- Autonomous target selection in NavCam images
- Autonomous pointing refinement in RMI images

***NavCam***



***RMI***






# ChemCam Collision Safety

"Protect the Spacecraft"

ChemCam must not be allowed to **shoot the rover**.


AEGIS software handles collision prevention automatically in some cases

Supported by collision safety procedures for operators, and training for instrument and mission ops personnel



## ***Mast view of rover, sol 2***

*Much of the rover hardware is in reach of ChemCam's laser, including sensitive instruments. The robotic arm (stowed in this view) must also be avoided.*



## ***ChemCam calibration target, sol 1126***

*This is what happens when ChemCam's powerful laser hits a plate made of solid titanium.*

*It is important to prevent ChemCam from shooting the rover anywhere but on the calibration target.*



# ChemCam Sun Safety

## “Protect the Instrument”

- ChemCam is sensitive and [cannot be pointed at the sun](#)
  - Not even transiently when slewing between LIBS targets
  - Must account for potential fault conditions: Exclude anywhere the sun could be anytime in the next ~month.
- All ChemCam targets/slews carefully planned and selected
- Sun-safety protections exist for science operations:
  - Operations rules and procedures
  - On-board software
  - Special focus position
- New sun-safety procedures for autonomous-targeting ops
  - Maximize science flexibility and targeting options
  - Minimize complexity
    - Potential for errors
    - Hesitation to use AEGIS if it appears complicated
- On-board commands can exclude portions of the Az/EI space around the rover

# Target distance rules

“Protect the instrument” & “Get good science data”


Risk to instrument from firing too close. (~2.2 m)

Science data becomes too noisy beyond ~7 m


Poor laser focus can cause loss of observation

AEGIS computes stereo range

- Rejects targets with poor range estimate
- Filters targets outside useful range of ChemCam



**Distribution of ChemCam targets**



## Example of stereo filtering

Red: Rejected for poor stereo estimation.

Yellow: Rejected out of range

Green: Passed filter





# Flight System Validation

## “Prove it works on Mars”




- **Each minute of time on Mars is a precious opportunity**
  - A large team of experts carefully consider each observation
- **The Curiosity rover is a sensitive, valuable, unique flight system**
  - The standard for protecting the rover is very high
- **The deployment of AEGIS means:**
  - Letting the computer choose science targets, instead of scientists
  - Placing a powerful laser under control of an intelligent computer system
- **AEGIS checkout activities were designed to verify and validate the software, its safety measures, and its effectiveness, on Mars, after extensive testing on Earth**
  - Does it run correctly in all modes and circumstances?
  - Does it protect the instrument and the vehicle?
  - Does it pick good targets?
  - Does it point ChemCam correctly to hit those targets & make good measurements?
- **7-step progressive checkout plan**
  - Worked up from running code only, to taking images of targets, to firing the laser at them
  - Plan approved by MSL mission authorities and ChemCam team

- AEGIS checkouts on MSL completed in early 2016
- System released for science team use May 2016
- First Use: sol 1343
- Target-finding parameters updated on sol 1400 with field experience
- NavCam (post-drive autonomous target selection) used 52 times, observing 57 ChemCam targets
  - After most drives
- RMI (autonomous pointing refinement) used 2 times
  - Only when important, small features are to be observed




# Results: Pointing refinement


- Sol 1424 & Sol 1463
- Small, bright features
  - RMI FOV: 20 mrad  $\emptyset$
- Initial (ground-selected) pointing missed target
- AEGIS corrected pointing and hit the target
- Saved observation – a manual retargeting second attempt would have been necessary. Not possible if rover were to drive in that plan




# Results: Target selection




Sol 1400



Sol 1417



Sol 1481




Sol 1636




# Results: Target selection

- Set to find outcrop
- Since sol 1400, has hit exclusively outcrop in 93% of cases
- Remaining cases were float rock and outcrop with some sand cover
- Blind targeting modeled for same sols
  - Previous technique for aiming at fixed position relative to rover post-drive


AEGIS As-Run  
Since Rollout




Blind Target Notional  
Since Rollout



AEGIS As-Run  
Since Sol 1400



Blind Target Notional  
Since Sol 1400




Outcrop  
Outcrop and Sand

Sand  
Rock and Sand

Rock



# More data from ChemCam



- Significant increase in rate of data return from ChemCam
- AEGIS rollout to science team on sol 1343