

The BiBlade Sample Chain and Experimental Results for Comet Surface Sampling

Paul Backes, Ph.D.

Jet Propulsion Laboratory


California Institute of Technology

May 10, 2017



Touch-and-Go Mission Concept Architecture

- Spacecraft maneuvers to several meters from surface of comet.
- Sampler is at end of robotic arm.
- Spacecraft descends until sampler contacts surface of comet.
- Acquire sample.
- Ascend away from comet.





Comet Surface Sample Return Requirements from the Decadal Survey

Group 1: From the Decadal Survey Primary Document

- Return a single ≥ 500 cc sample from the surface of any comet nucleus
- Preserve sample complex organics (sample using a "soft" technique)
- Prevent aqueous alteration of the sample at any time (maintain at ≤ -10°C)

Group 2: In Decadal Survey Appendix Mission Study Document

- If the sampled region has shear strength <= 50 kPa
 - Return material from depth >= 10cm (~3 diurnal thermal skin depths)
 - Maintain sample stratigraphy
- Determine whether the sample is from an active or inactive nucleus region



Full-scale Sampling Validation






Sample Chain



Pull blades back compressing springs (one actuator for all operations)



Sample in ~ 30 ms (fast) and retract (tapered blades prevent binding)




Insert into sample measurement station and image with 9 fiberscopes



Insert into SRC and release lid via frangibolt (repeat for second sample)




End-to-end Sampling Chain Testbed





BiBlade Sampling Chain




(A) Approach; (B) Springs drives blades into simulant; (C) Transfer to Sample Return Capsule (SRC); (D) Sample measurement using Fiberscope Sample Imager; (E) Insert BiBlade into SRC vault and retract blades; (E) Fire Frangibolt to release lid and contain sample; (F) Retract; (G) (H) Show results by opening sample yault and displaying acquired sample.





BiBlade Features


- Sample volume: 500 cc
- Depth: 10% below 10 cm
- Sample strength: 0 5 MPa CPR
- Sampling and encapsulation in ~40 ms
- Acquires and stores two samples from two separate sites
- Enables multiple attempts per sample
- Fully tapered blades for robust extraction from comet
- Direct measurement of sample with nine-fiberscope imaging
- Mechanically simple requiring only one actuator and two frangibolts















BiBlade Design






BiBlade Design





Gripper Mechanism






Mechanical Porous Ambient Comet Simulant (MPACS)

- Ingredients: Portland cement and pumicite combined and added to water and a foaming agent.
- Strength properties were varied by changing the amount of foaming agent added to the mixture.
- The MPACS material was fabricated into 8-inch cubic boxes for the BiBlade test program.
- Density, cone penetration resistance (CPR), uniaxial compressive strength (UCS), shear strength, and porosity were measured.






Sampling Testbed





Low End Sampling Results – Sampling Into Fly Ash




Ejecta plate
 redirects ejecta
 to the side, away
 from spacecraft



Survive Hitting Hardest Material

Tool survives hitting cinder block at maximum blade velocity, having only one blade strike. Overload springs absorb impact energy.





Robustness to Off-nominal Samples and Transfer Conditions





Robustness testing of sample transfer process/hardware.

- (A) Frangibolt actuation is included in the sample lid release.
- (B) Off-nominal samples are forced to test insertion and stowage robustness to extreme scenarios.
- (C) Positional error was intentionally commanded to evaluate limits of selfalignment during tool insertion.



Sample Measurement: Fiberscope Sample Imager





Bi-blade
Sampler
Objective Lens
I Imaging Fiber
Riber
Station

Microscope
Objective Lens
CAMOS image
Sensor

Station

According to the state of the


Nine fiberscopes along the walls of the measurement chamber passively transfer views of the sample surface to a common camera



Thermal Vacuum Chamber Testing

- Cycling between +70°C and -160°C (three cycles)
 - Sampler thermal control system maintained cold phase tool temperatures between the thermostat set points, -32°C to -25°C
- Pressure 10⁻⁷ torr (high vacuum)
- Functional testing
 - Actuator homing s at each cold cycle
 - Functional test at last cold phase consisting of self-fire sampling operations five times
- Performance verification
 - Verify thermocouples read values within allowable flight temperatures of the components
 - Verify surfaces contacting sample (blades) do not exceed -25°C
 - Verify that actuator maintains adequate torque/current margin
 - Verify kinetic energy available for sampling (blade speed) within 5% of Standard Temperature/Pressure condition


Cold shroud end plate and top half of BiBlade thermal/dust shroud removed for photo.





Integrated Proximity Operations and Sampling

- Mounted BiBlade on air-levitated robotic spacecraft and demonstrated autonomous Touchand-Go approach, sampling, and ascent.
- In JPL Formation Control Testbed.







Contributors

Paul Backes¹, Scott Moreland¹, Fredrik Rehnmark², Mircea Badescu¹, Kris Zacny², Robert Wei², Grayson Adams², Risaku Toda¹, Peter Vieira¹,

Elizabeth Carey¹, Robert Krylo¹, Miguel San Martin¹, Erik Bailey¹, Carl Seubert¹, Dylan Conway¹, Seth Aaron¹, Harish Manohara¹, Gregory Peters¹, Marco Mongelli¹, Dario Riccobono¹

¹Jet Propulsion Laboratory California Institute of Technology 4800 Oak Grove Dr. Pasadena, CA 91109 Paul.G.Backes@jpl.nasa.gov

²Honeybee Robotics 398 W. Washington Blvd. #200 Pasadena CA 91103 zacny@honeybee.com



The research described in this publication was carried out at the Jet Propulsion Laboratory, California Institute of Technology, under a contract with the National Aeronautics and Space Administration (NASA). The work was performed as part of a task in the NASA Maturation of Instruments for Solar System Exploration program. Sampling requirements associated with science for comet surface sample return were provided by Dr. Carol Raymond and Dr. Mathieu Choukroun.

© 2017 California Institute of Technology. Government sponsorship acknowledged.