


Multiangle Spectropolarimetric Imagers for Aerosol

Giacomo Mariani

John C. Pearson, Kevin Burke, David J. Diner



Superconducting Materials and Devices Group
NASA Jet Propulsion Laboratory - California Institute of Technology

September 14, 2017


Copyright 2017 California Institute of Technology.
U.S. Government sponsorship acknowledged.

- Particulate matter and health
- Spectropolarimetric imager description
- Observing modalities
- Camera architecture
- Focal Plane Module
- Packaging
- Spectropolarimetric filters
- Conclusions

Particulate matter (PM) impacts on human health

2

Science framework



Airborne PM is a well-known cause of cardiovascular and respiratory diseases.


Coarse particles (PM_{10} - $PM_{2.5}$) irritate our respiratory systems.

Fine particles ($PM_{2.5}$) penetrate deep into our lungs. Toxins can migrate to other organs.

- Heart attacks
- Stroke
- Lung disease, lung cancer
- Aggravated asthma
- Low birth weight and preterm delivery



3 Slicing up the spectrum



- ✓ Although PM is implicated in many adverse health impacts, the relative toxicity of specific **PM types** is not well understood
- ✓ PM “type” refers to the fractional proportions of PM₁₀, PM_{2.5}, and PM_{2.5} components (sulfate, nitrate, organic carbon, black carbon, dust)
- ✓ According to the US EPA (2013)
 - The evidence is not yet sufficient to allow differentiation of those constituents or sources that may be more closely related to specific health outcomes.
 - *The use of central fixed-site monitors to represent population exposure is a key factor limiting our knowledge as to which PM types pose the greatest health risks.*

4 Technical capabilities

Instrument

Two pushbroom spectropolarimetric cameras on a 2-axis gimbal

A bit larger than a large microwave oven

Investigation

Obtain data for globally distributed Primary Target Areas


- Instrument observations
- Ground station observations
- Chemical transport model outputs
- Health records

Obtain data for globally distributed Secondary Target Areas, Calibration/Validation Target Areas, and Targets of Opportunity

Analyses and Findings

Reporting on

- Epidemiological investigations of health impacts of particulate pollution
- Other mission science
- Instrument performance, calibration, and validation



Imager can integrate multiple observing modalities

5

Observing modes

Multi-angle radiometry

Enhances the aerosol signal relative to surface reflection

Sensitive to aerosol particle size and shape

Precursors: MISR, AATSR, POLDER, AirMSPI


Broad spectral coverage

UV: aerosol absorption and height

VNIR: Fine mode aerosols

SWIR: Coarse mode aerosols


Precursors: MODIS, TOMS, OMI, GLI



Multi-angle polarimetry


Sensitive to particle size and compositional proxies such as refractive index

Precursors: POLDER, airborne RSP, AirMSPI




- ✓ The instrument is a gimbaled pushbroom camera system
- ✓ The camera architecture uses the spectropolarimetric imager approach developed for AirMSPI and AirMSPI-2
- ✓ Detector rows are overlaying with stripe spectral filters and patterned wiregrid polarizers
- ✓ Polarization signals are modulated using photoelastic modulators (PEMs) and achromatic quarter-wave plates (QWPs)
 - Modulation provides significantly greater accuracy than static polarimetry

7 Focal Plane Module (FPM)




- ✓ Several requirements are imposed on the FPM design, including:
 1. Electronic Interface – Power, housekeeping, and data rates
 2. Filter smoothness and cleanliness – minimize stray light
 3. Dark current levels – ensure adequate SNR for science req's
 4. Pixel arrangement – dictated by design at the ROIC level
 5. Spectral quantum efficiency – UV/Vis silicon photodiodes, IR
HdCdTe detector




ROIC detector array mounted on a test board showing 130 wire bonds

- ✓ The UV/VNIR and SWIR ROICs share the same reticle and have the same number of pixels ($1280 \text{ pixels} \times 128 \text{ rows}$) and pixel size ($15 \mu\text{m} \times 15 \mu\text{m}$)
- ✓ SWIR row pitch is $15 \mu\text{m}$ and the UV/VNIR row pitch is $20 \mu\text{m}$
- ✓ UV/VNIR array uses integrated (on-chip) photodiodes, and the SWIR array uses hybridized HgCdTe p+/n photodiodes (Teledyne)
- ✓ UV/VNIR and SWIR arrays are separated by a gap
- ✓ The two designs are electrically isolated, except for the common substrate

Heritage



Current



Haywires



Proposed jumper-wired connections

Solid core technology demonstrated

11



Focal Plane Module

	Heritage (AirMSPI-2)	Current design	Implementation
Packaging	CPGA/rigid-flex	CPGA/board	Standard engineering practice
	Soldered CPGA	Jumpered wires	Tested for stress relief
Electronics Interface	Connectors on flex	Connectors on board	Streamlined mate/demate
ROIC design	Minor fixes post-fab	Peer-reviewed fixes incorporated	ROIC fabrication

- ROIC is a schedule-critical item
- ROIC is well understood, mods use proven practices
- All functionalities from design baseline are implemented in the current instrument
- Wafer screening process underway to identify candidates

12

Focal Plane Module



- ✓ Simultaneously front- and back-lit photograph of the AirMSPI-2 spectropolarimetric filter
 - Shows the stripe spectral filters and patterned polarizers
- ✓ Unique integrated assembly which starts from a wiregrid polarizer substrate
- ✓ Butcher-block type filter assembly is aligned and built directly onto polarizer substrate


13

Focal Plane Module


Band	Center wavelength (nm)	QE (%) [*]	Active detector rows
1	365	4	1
2	385	8	1
3	415	20	1
4	445	27	2 (polarimetric)
5	550	50	1
6	645	52	2 (polarimetric)
7	749	33	1
8	762	33	2
9	867	17	2
10	945	6	2
11	1035	72	4 (polarimetric)
12	1610	75	1
13	1880	80	1
14	2125	82	1

UV/VNIR array

SWIR array

^{*}Quantum efficiency based on previous detector performance


Filter aligned to the detector array and bonded to the custom ceramic pin grid array



- ROIC is a JPL-design, externally fabricated
- Wafer screening occur before hybridization of MCT detector
- Testing #1 will verify most of the electrical functionalities of the ROIC/detector
- Testing #2 will verify all the opto-electrical functionalities of the FPM

- ✓ Spectropolarimetric imagers based on pushbroom cameras are presented
- ✓ Integrated capabilities of multi-angle radiometry, broad spectral coverage, multi-angle polarimetry drive epidemiological investigations of health impacts of particulate pollution
- ✓ JPL-designed ROIC allow for UV/Vis and IR sensing on the same chip
- ✓ ROIC + spectropolarimetric filters will constitute the focal plane modules to be integrated at the camera level