



**Jet Propulsion Laboratory**  
California Institute of Technology

# **A few results from radiation transport tool comparison study at JPL**

**Presented by Insoo Jun**  
**On behalf of the Natural Space Environments Group**

**Jet Propulsion Laboratory, California Institute of Technology**

**September, 7 2017**


Copyright 2017 California Institute of Technology. Government sponsorship acknowledged.

# Topics

- Survey of radiation shielding tools
  - Introduction of widely used radiation shielding tools
  - Primary applications of radiation transport tools
- NOVICE vs. FASTRAD for TID
- NOVICE vs. MCNPX for Dose-Depth Curve
- Geant4 vs. MCNPX for Pulse-height Simulation in a Thin Silicon Layer

# Ray Tracing Codes

- Ray tracing codes are useful to perform system level trade studies fast
- Ray-tracing codes with CAD interface capability would be very useful
- Tools available:
  - FASTRAD: <http://trad.fr/>
  - MEVDP: <http://www-rsicc.ornl.gov/>
  - “SIGMA” option in Novice: [tj@empc.com](mailto:tj@empc.com)



# Transport Codes – Species

- Transport codes model actual particle interactions in the material (Ray tracing codes do not)
- It is important to model all particle species when performing transport analyses
  - Electrons
  - Photons
  - Protons
  - Neutrons
  - Heavy Ions
- Each transport code considers only a specific set of particles

**Radiation transport analyses will be required to cover a wide range of particle species**

# Commonly Available Radiation Transport Codes

	Electron	Photon	Proton	Neutron	Heavy Ion
CREME96 <a href="http://creme96.nrl.navy.mil">creme96.nrl.navy.mil</a>			O		O
TRIM <a href="http://www.srim.org">www.srim.org</a>			O		O
ITS3.0 <a href="http://www-rsicc.ornl.gov">www-rsicc.ornl.gov</a>	O	O			
NOVICE <a href="mailto:tj@empc.com">tj@empc.com</a>	O	O	O		O
MCNP(X) <a href="http://mcnpx.lanl.gov">mcnpx.lanl.gov</a>	O	O	O	O	O
Geant4 <a href="http://geant4.web.cern.ch/geant4/">geant4.web.cern.ch/geant4/</a>	O	O	O	O	O

Other radiation transport codes are available: EGS4, CEPXS, HZETRN, PHITS, PENELOPE, FLUKA, MARS, etc.

# Transport Codes – Applications

- Transport codes are needed to consider the following
  - Total ionizing dose
  - Displacement damage dose
  - Single event effects
  - Internal charging
  - Secondary particle environment behind shield
- Transport codes can be used for particle detector simulation

**Radiation transport analyses are used to cover a wide range of radiation effects**



# Features of Common Transport Codes

Code	Primary Application	Comments
CREME96	Heavy Ion LET Spectra	Limited to spherical shell aluminum shielding
TRIM	Proton or heavy ion beam simulation	1-dimensional Only Coulomb interaction
ITS3.0 (TIGER)	Electron or photon beam simulation for dose and charging rate profiles	Excellent electron/photon physics Extensively benchmarked
NOVICE	Spacecraft level shielding analysis	“Adjoint” (fast for space environment application) No secondary neutrons Not accurate for secondary electrons
MCNP(X)	Full 3-D detector/sensor simulation Transients calculation	Good physics and extensive development history Slow for space application
Geant4	Full 3-D detector/sensor simulation Transients calculation	Good physics Many Geant4-based “tools” are available Slow for space application

**Comments are based on current JPL experience**

# **FASTRAD - NOVICE**







Figure 1. A Spherical Shell in a Spherical shell Container

**Table 1. Dose Comparison for a Configuration of Spherical Shell in Spherical Shell Container**


3D Mass Model	Computer Code	Ionizing Dose (krad, Si) [RDF = 1]			
Simple 3D Geometry (A spherical shell in a spherical shell container)		Electron	Photon	Proton	Total
<ul style="list-style-type: none"> <li>Inner Shell (<b>Aluminum</b>, 2.5 mm)</li> <li>Outer Shell (<b>Aluminum</b>, 2.5 mm)</li> </ul>	FASTRAD	277.80	2.03	8.91	288.7
	NOVICE	273.0	2.01	8.90	283.9
<ul style="list-style-type: none"> <li>Inner Shell (<b>Tantalum</b>, 2.5 mm)</li> <li>Outer Shell (<b>Aluminum</b>, 2.5 mm)</li> </ul>	FASTRAD	87.03	3.49	0.99	91.5
	NOVICE	41.90	6.86	2.04	50.8
<ul style="list-style-type: none"> <li>Inner Shell (<b>Tantalum</b>, 2.5 mm)</li> <li>Outer Shell (<b>Tantalum</b>, 2.5 mm)</li> </ul>	FASTRAD	36.39	3.93	0.41	40.7
	NOVICE	8.45	7.27	0.96	16.7



## A Box Containing Two Boards in a Cylindrical Container


**Table 2. Dose Comparison for a Configuration of Box in Cylindrical Container**

3D Mass Model	Computer Code	Ionizing Dose (krad, Si) [RDF = 1]			
Simple 3D Geometry (A Box with 2 boards in a Cylindrical Container)		Electron	Photon	Proton	Total
<ul style="list-style-type: none"> <li>Box Wall (<b>Aluminum</b>, 2.5 mm)</li> <li>2 PCB (<b>Aluminum</b>, 1.5 mm)</li> <li>Container Wall (<b>Aluminum</b>, 2.5 mm)</li> </ul>	FASTRAD	200.94	2.45	4.63	208.0
	NOVICE	210.0	2.50	4.72	217.2
<ul style="list-style-type: none"> <li>Box Wall (<b>Tantalum</b>, 2.5 mm)</li> <li>2 PCB (<b>Aluminum</b>, 1.5 mm)</li> <li>Container Wall (<b>Aluminum</b>, 2.5 mm)</li> </ul>	FASTRAD	60.08	3.74	0.66	64.5
	NOVICE	33.8	6.74	1.33	41.9
<ul style="list-style-type: none"> <li>Box Wall (<b>Tantalum</b>, 2.5 mm)</li> <li>2 PCB (<b>Tantalum</b>, 1.5 mm)</li> <li>Container Wall (<b>Tantalum</b>, 2.5 mm)</li> </ul>	FASTRAD	16.02	3.80	0.23	20.1
	NOVICE	3.19	6.25	0.51	10.0



**Table 3. Dose Comparison for an Electronics Box CAD Model**

3D Mass Model	Computer Code	Ionizing Dose (krad, Si) [RDF = 1]			
		Electron	Photon	Proton	Total
<b>Electronics Box CAD Model</b>					
<ul style="list-style-type: none"> <li>Entire Electronics Box (Aluminum)</li> </ul>	FASTRAD	365.6	2.69	13.4	381.7
	NOVICE	356	2.93	13.4	372.3
<ul style="list-style-type: none"> <li>Entire Electronics Box (Tantalum)</li> </ul>	FASTRAD	60.02	2.48	1.10	63.6
	NOVICE	54.8	4.29	3.01	62.1



(A picture generated by FASTRAD)

**Figure 4. Spot Shielding in Electronics Box CAD Model**

**Table 4. Dose Comparison for Spot Shielding Inserted in Electronics Box CAD Model**

3D Mass Model	Computer Code	Ionizing Dose (krad, Si) [RDF = 1]			
		Electron	Photon	Proton	<b>Total</b>
Electronics Box with a manually inserted spot shielding					
<ul style="list-style-type: none"> <li>Entire Electronics Box (<b>Aluminum</b>)</li> <li>Spot Shielding (<b>Aluminum</b>, 4.8 mm thick box wall)</li> </ul>	FASTRAD	96.88	3.26	1.78	101.9
	NOVICE	111.0	3.49	1.8	116.3
<ul style="list-style-type: none"> <li>Entire Electronics Box (<b>Aluminum</b>)</li> <li>Spot Shielding (<b>Tungsten</b>, 4.8 mm thick box wall)</li> </ul>	FASTRAD	8.10	3.54	0.15	11.8
	NOVICE	1.96	4.41	0.30	5.67

# Summary for NOVICE vs. FASTRAD

- Based on the above calculations and comparisons, FASTRAD is considered a **conservative** radiation dose estimation tool. Its built-in ray tracing function can generate dose estimate in a **very short period of time**. Its fast calculation capability significantly outpaces the more sophisticated NOVICE code when complex CAD model was involved. Its **real-time visualization** capability provides radiation engineers the tool to easily select parts location and perform optimum shielding design and analysis by moving components or adding shielding in the existing CAD file.
- After the “preliminary” radiation dose estimates are done, NOVICE code could be used to calculate the more precise radiation dose values when the hardware design is “finalized”.

**NOVICE – MCNPX**




Fig. 2. Ionizing doses calculated for a detector located at the center of spherical shell shielding of aluminum and tungsten in a 30-day Europa mission with NOVICE and MCNPX, respectively. (100 rad = 1 Gray).






Fig. 3. Ionizing doses calculated with NOVICE for a detector located at the center of the spherical shell shielding of aluminum, tungsten, and 50% areal mass aluminum (outer layer)/50% areal mass tungsten (inner layer) combination in a 30-day Europa mission. (100 rad = 1 Gray).





# **MCNPX – GEANT4**

# Firefly Beam-Line Tests of Detector


## BNL Electron Beam-Line Tests and Simulations



## UC Davis Proton Beam-Line Tests and Simulations



### BNL Test - Run 13



# Summary

- Radiation transport codes are needed to:
  - Estimate doses and other radiation effects
  - Design radiation shield
  - Understand instrument's response to radiation
- Different codes should be used for different applications and for different radiation type
- Benchmark study (including beam testing) is recommended to validate simulation results for specific hardware application
  - This is especially true for science instrument simulations

**THANK YOU!**

**QUESTIONS?**