



Jet Propulsion Laboratory
California Institute of Technology

The Cuprite Project: Mineral Unmixing in the Longwave Infrared

Kerry Cawse-Nicholson, Simon Hook, Glynn Hulley

Jet Propulsion Laboratory, California Institute of Technology


Mineral detection ranges

		Structure	Mineral Group	Example	VNIR Response	SWIR Response	LWIR Response
	Silicates	Inosilicates	Amphibole	Actinolite	Non-Diagnostic	Good	Moderate
			Pyroxene	Diopside	Good	Moderate	Good
		Cyclosilicates	Tourmaline	Elbaite	Non-Diagnostic	Good	Moderate
		Nesosilicates	Garnet	Grossular	Moderate	Non-Diagnostic	Good
			Olivine	Forsterite	Good	Non-Diagnostic	Good
		Sorosilicates	Epidote	Epidote	Non-Diagnostic	Good	Moderate
		Phyllosilicates	Mica	Muscovite	Non-Diagnostic	Good	Moderate
			Chlorite	Clinocllore	Non-Diagnostic	Good	Moderate
			Clay Minerals	Illite	Non-Diagnostic	Good	Moderate
				Kaolinite	Non-Diagnostic	Good	Moderate
		Tectosilicates	Feldspar	Orthoclase	Non-Diagnostic	Non-Diagnostic	Good
				Albite	Non-Diagnostic	Non-Diagnostic	Good
			Silica	Quartz	Non-Diagnostic	Non-Diagnostic	Good
	Non-Silicates	Carbonates	Calcite	Calcite	Non-Diagnostic	Moderate	Good
			Dolomite	Dolomite	Non-Diagnostic	Moderate	Good
		Hydroxides		Gibbsite	Non-Diagnostic	Good	Moderate
		Sulphates	Alunite	Alunite	Moderate	Good	Moderate
				Gypsum	Non-Diagnostic	Good	Good
		Borates		Borax	Non-Diagnostic	Moderate	Uncertain
		Halides	Chlorides	Halite	Non-Diagnostic	Uncertain	Uncertain
		Phosphates	Apatite	Apatite	Moderate	Non-Diagnostic	Good
		Hydrocarbons		Bitumen	Uncertain	Moderate	Uncertain
		Oxides	Hematite	Hematite	Good	Non-Diagnostic	Non-Diagnostic
			Spinel	Chromite	Non-Diagnostic	Non-Diagnostic	Non-Diagnostic
		Sulphides		Pyrite	Non-Diagnostic	Non-Diagnostic	Non-Diagnostic

Source: TerraCore Africa, with permission.

Cuprite

Age	Map/Drill Ht. Symbol	Thickness (meters)	Column	Formation
Quaternary	Qa	0 - 3		Alluvium
	Qp	0 - 5		Pediment Alluvium
	TQoa	3		Old Alluvium
	Tb2	3		Pediment Basalt
Miocene	Trs	0 - 100		Rabbit Springs Formation
	Tsf2	18 - 24		Civet Cat Canyon Mb.
	Tsf1	18 - 30		Spearhead Mb.
	Tb1	0 - 10		Porphyritic Basalt
	Tch	0 - 15		Cuprite Hills Conglomerate
	Tst	85 - 160		Siebert Tuff
Oligocene	Tw	> 100		Ashflow Tuff
Mt. & Upper Cambrian	Ee	~1700		Emigrant Fm.
Lower Cambrian	Ems	~140		Mule Spring Limestone
	Eh			Quartz Latite Dikes
	Eh	~1000		Syenomonzonite Dikes
	Ehl			Harkless Fm.
	Ep	~600		Poleta Fm.





HyTES




Instrument Characteristic	HyTES
Mass (Scanhead)	12kg
Power	400W
Volume	1m x 0.5m (cylinder)
Number of pixels x track	512
Number of bands	256
Spectral Range	7.5 - 12 μm
Spectral Sampling Interval	4.5 μm /256, i.e. 17 nm
Frame speed	35 or 22 fps
Integration time (1 scanline)	28 or 45 ms
Total Field of View	50 degrees
Calibration (preflight)	Full Aperature Blackbody
Detector Temperature	40K
Spectrometer Temperature	100K
Slit Length and Width	20 mm x 39 μm
IFOV	1.7066
Pixel Size/Swath at 2,000 m flight altitude	3.41m/1868.33m
Pixel Size/Swath at 20,000 m flight altitude	34.13m/18683.31m


Mineral features




Mineral features




Mineral features




Mineral features






Tetracorder


- Tetracorder (Clark, Swayze and Livo, et al. 2003), is perhaps the best-known rule-based mineral mapping system.
- The algorithm first removes the continuum of the spectrum.
- Next, diagnostic wavelength ranges (the range containing local minima unique to a particular mineral type) are used along with an extensive library of minerals to identify mineral classes.
- A number of other rules avoid false matches, including a comparison at both reflectance and continuum-removed level.




19 October 2017




Cuprite




Swayze et. al. *Econ. Geol.* 2014



19 October 2017



Cuprite



Swayze et. al. *Econ. Geol.* 2014

Summary

- The long-wave infrared needed to accurately map silica and feldspar minerals.
- However, it is complimentary to the short-wave infrared for mineral mapping. Ideally, an extended spectral range is needed.
- Unsupervised mineral mapping techniques show promising preliminary results when using spectral feature separation.



Jet Propulsion Laboratory
California Institute of Technology

jpl.nasa.gov