

# Mars Deep Drilling Concept

## JPL Strategic Investment Task FY2018

Brian Wilcox

Jet Propulsion Laboratory, California Institute of Technology

KISS Workshop

15 Feb 2018

© 2018 California Institute of Technology. Government sponsorship acknowledged.

# Percussion Drilling



- Each blow of a hammer causes hard teeth (e.g. tungsten carbide) to break the rock face at each tooth.
- A fluid (liquid or gas) flushes out the cuttings.
- The bit is rotated by a small angle and the process repeats.
- The angle is carefully chosen so that all areas of the hole face are broken before the cycle of impact locations repeat.

# Why Percussive Deep Drilling?

- Rule-of-Thumb in petroleum drilling industry is that the Weight-on-Bit (WOB) for diamond drag (e.g. not percussive) drill bits needs to be  $\sim 4000$  pounds of force (lbf) per inch of bit diameter. (Each diamond cutter is at a different radius and cuts its own groove. So the number of cutters is proportional to the diameter, and each cutter needs a set force.)
- The torque is proportional to the WOB times the drill diameter.
- This linear relationship between diameter and torque is to be compared to the cubic relationship between a steel shaft diameter and its allowable torque.
- The net result is that no materials exist which can deliver enough torque in a small hole - at 0.5GPa stress a solid steel shaft meets the rule-of-thumb at a diameter of 1.4 cm.


# Small-Hole Percussive Drilling of Basalt in 2003-4

- Fixture built using commercial rotary-percussive core drill to measure static and dynamic reactions during coring operations on basalt



## Threshold in Impact Energy to Break Basalt

### Specific Energy of Percussive Basalt Destruction versus Hammer Energy



# Wireline Systems in Drilling

- Wireline refers to spool of tether between downhole assembly lowered into hole using a winch spool.
- Drilling can be accomplished by having downhole assembly excavate cuttings into a "muck bucket", which is raised to surface when downhole assembly is winched up using wireline.
- Muck bucket is emptied, any maintenance or repair is performed on downhole assembly, and downhole assembly is lowered back into hole to repeat process.
- Wireline can transmit necessary power and/or data to downhole assembly.
- Lining of hole is not accomplished by these systems, so effective only when drilling through competent rock.





Image from [Patent US6229453](#)



# Mars Deep Subsurface Drilling Concept



## Objectives:

- The objective of this task is to analyze and test methods for penetrating deep (1-10 km) into the Mars Subsurface environment within the mass, power, planetary protection, and cost constraints of realistic near-term robotic Mars missions.

## Approach:

- The initial approach is to examine wireline drilling using a CO<sub>2</sub>-powered rotary-percussive downhole assembly, requiring minimum weight-on-bit, that is tripped out of the hole regularly to dump cuttings.

## Mission Concept:


- Land system as payload on MSL-class rover,
- Rove around until a suitable rock outcrop is located.
- Make ~1 km loop around outcrop, dropping fine wire used as Ground-Penetrating Radar antenna.
- Return to outcrop and connect to both ends of wire loop.
- Begin GPR sounding to establish that rock is likely to be competent all the way to the subsurface aquifer. (If not, may seek other site; can have extra spools of wire.)
- Begin drilling.

## Advantages:

- Relatively easy to sterilize downhole assembly and related equipment via dry-heat sterilization to several hundred degrees Celsius.
- Weight of downhole assembly provides sufficient weight-on-bit for rotary-percussive drill mechanism.
- Relatively small torque-reaction against sidewall (provided by "toothed rollers" which are spring-loaded against bare rock inside face of hole.
- Mass of system essentially independent of maximum depth, since hole is not lined and spool of wireline is lightweight.


# JackHammer


- Basic concept of pneumatic jackhammer patented in 1894.
- Reciprocating valve out of phase with reciprocating hammer.






# Hammer Drill (slowed)






# 1 Gen Manufactured (test reciprocating mechanism)




# 3D-Printed Stainless (316 alloy) Hardware



Micro-hydraulic motor

MH450 DS



Shaft, flanges, inlet and outlet ports can all be adapted to your need, under specific conditions; please contact us.

from [http://www.hydroeduc.com/images/links/catalogues/hydro%20educ%20documentation\\_en/micro%20hydraulics/hydroeduc\\_micro\\_en.pdf](http://www.hydroeduc.com/images/links/catalogues/hydro%20educ%20documentation_en/micro%20hydraulics/hydroeduc_micro_en.pdf)



# Fused Silica Capillary Tubing

## Polymicro Technologies™ Polyimide Coated Fused Silica Capillary Tubing

Delivering industry-leading performance including tight ID and OD tolerances, Polymicro Technologies™ polyimide coated TSP and high-temperature TSG capillary tubing ensures precise flow-rate control of liquids and gases for Scientific, Industrial and Medical applications

### Features and Benefits

Pure synthetic fused silica capillary

Mirror-smooth interior surfaces for stable flow of liquids and gases. Low metal ion content provides an inert inner surface. Facilitates efficient cleaving or cutting for custom lengths of tubing

Wide range of internal and external diameters with tight dimensional control

Enables design flexibility and operation efficiency. Superior dimensional stability over long lengths of tubing. External diameters mate with existing industry equipment connector technologies

TSP and TSG polyimide coatings

Offer excellent abrasion resistance during handling and usage. Resist temperatures up to +350°C for TSP; up to +400°C for TSG. Allow product flexure with superior bend radius


Custom options available

Boost design efficiency. Provide small production values at reasonable costs. Ensure prototype methodology is directly scalable to high volume with minimal design costs

**molex®**



Polymicro Technologies™  
Polyimide Coated Capillary Tubing



Fused Silica Capillary Diagram

from [https://www.molex.com/molex/products/family?key=polymicro\\_capillary\\_tubing&channel=products&pageTitle=Introduction](https://www.molex.com/molex/products/family?key=polymicro_capillary_tubing&channel=products&pageTitle=Introduction)

We are using 1000 meters of model TSP450670 (450μ ID, 625μ OD+24μ polyimide coating)

# Liquid CO<sub>2</sub> Pump powers downhole assembly

- Downhole assembly powered by pressurized liquid CO<sub>2</sub>.
- Liquid CO<sub>2</sub> can be ordered via JPL iProcurement.

## Model SFC-24 Pump

Positive Displacement Pump for Liquid CO<sub>2</sub>



### Reliable, Accurate and Consistent Performance

The Model SFC-24 Positive Displacement Pump provides reliable, accurate and reproducible pumping of liquid CO<sub>2</sub> for SFC, SFE, and other applications. The SFC-24 is available with a maximum flow rate of 24 mL/min, and can reach pressures to 10,000 psi.

The pump's constant pressure mode features a selectable pressure set point. The flow rate auto-adjusts to maintain pressure. The SFC-24 features integrated cooling systems using Peltier thermoelectric modules.

### Easy Maintenance

The cooling is fully self-contained within the pump cabinet, eliminating the need for external refrigeration units and the associated piping, coolants, and Freon. Peltier technology is 100% solid state.

### Standard Features

- All aluminum pump heads (for heat transfer)
- Integrated cooling system using Peltier thermoelectric modules
- Stainless Steel fluid path (other than pump heads)
- In-line electronic pressure transducer
- Simple front panel keypad controls with led display
- Motor stall detector
- Outlet filter
- RS232 and remote voltage control standard

All Pumps carry a 3-Year Warranty.

PSG1019-RevD-041715

**SSI** Scientific Systems, Inc.  
Designed from Experience. Built for the Future.  
[www.ssi/hplc.com](http://www.ssi/hplc.com)


Scientific Systems, Inc.  
349 North Science Park Road  
State College, PA 16803

Phone: 800-441-4752 • 814-234-7311  
Fax: 814-234-2480 • 814-238-6072  
Email: [sales@ssihplc.com](mailto:sales@ssihplc.com)

from <https://www.instrument-solutions.com/wp-content/uploads/SSI-Scientific-supercritical-SFC-24-Pump.pdf>



# CO<sub>2</sub> Equation of State




- Liquid flashes to vapor at ~8 MPa @ 20°C

# Compressed CO<sub>2</sub> as Energy Source

- CO<sub>2</sub> compressed to 35 MPa (5000 PSI) releases >800 Joules per gram as it decompresses.
- 73% of energy comes as liquid decompresses from 35 to 8 MPa.
- 27% comes as vapor decompresses from 8 MPa to zero.

## Energy per Gram per MPa pressure drop (CO<sub>2</sub> starting at 35MPa and 20C)

Total 813.9 J/g (223.6 <8MPa and 590.3 >8MPa)



data from NIST Chemistry WebBook

24 ml/min @35MPa = 342 Watts of mechanical power

Predecisional information, for planning and discussion only

# Summary and Conclusions

- Wireline rotary-percussive downhole assembly powered by compressed liquid CO<sub>2</sub> offers a way to drill nearly unlimited distances in competent rock with very little mass overhead (extra mass per meter of extra distance).
- Entire downhole assembly is composed of parts rated at many hundreds of degrees Celsius for dry heat sterilization on way to Mars.
- Current effort should demonstrate key elements of concept this year.