



Keith J. Billings, Ratnakumar Bugga, Keith B. Chin, John-Paul Jones, Simon C. Jones, Charlie Krause, Adam Lawrence, Raymond Ontiveros, Jasmina Pasalic, Marshall C. Smart, and William C. West, Erik J. Brandon

Electrochemical Technologies Group

Jet Propulsion Laboratory, California Institute of Technology 4800 Oak Grove Drive, Pasadena, CA 91109 Erik.J.Brandon@jpl.nasa.gov

Space Power Workshop


Los Angeles, CA Thursday, April 23, 2018

© 2018 California Institute of Technology. Government sponsorship acknowledged

Pre-Decisional Information -- For Planning and Discussion Purposes Only

Increasing Interest in a lander for "Ocean Worlds"








Three Examples of Primary Batteries for Space



Galileo Probe 1989: Li/SO₂ ~580 Wh 58 minutes

Sojourner Rover 1996: Li/SOCl₂ 432 Wh 56 days (PV + battery)

Huygens Probe 2004: Li/SO₂ ~2700 Wh 153 minutes




A Europa Lander could require at least 480 hours of operation on battery power alone, therefore, high specific energy is critical to achieving mission objectives

Pre-Decisional Information -- For Planning and Discussion Purposes Only

Li/CF_x cells provide 50% more energy than heritage cells





- Discharged at the same condition
- 0 °C, 250 mA
- Li/FeS₂ discharged at 100 mA due to size (AA instead of D)
- 2 Li/FeS₂ cells could be connected in series to provide comparable voltage




- Jupiter generates a high radiation environment
- Europa is directly in the path
- Possible sterilization procedure for planetary protection
- JPL high dose rate ⁶⁰Co source
 - 1.3 MeV gamma rays
 - ~200 rad/s
 - 1 MRad up to 15 MRad

Test articles:

- Rayovac Li/CF_X D-cells
 - LiBF₄ in PC+DME
- Eagle-Picher Li/CF_X-MnO₂ D-cells
 - LiCIO₄ in PC+DME+THF
- 3-electrode Li/CF_X cells
- Cell components (cathode materials, salts, electrolytes, separators)








By Ruslik0 - Own work, CC BY-SA 3.0, https://commons.wikimedia.org/w/index.php?curid=6555923

Materials testing – XRD analysis

Pure CF_X and CF_X-MnO₂ cathodes do not change significantly during exposure to 10 MRad










LiCIO₄ appears to change due to 10 MRad, while LiBF₄ does not













Pre-Decisional Information -- For Planning and Discussion Purposes Only

Rest OCV and Impedance Analysis of Li/CF_x-MnO₂ Cells






- OCV monitored for >15 hours
- Linear regression analysis shows a slight voltage drop (0.18 to 0.2 mV/hr) for higher dose cells (4, 8, 15 MRad)
- No change in impedance after radiation
 - Spectrum slightly shifted due to connections



Pre-Decisional Information -- For Planning and Discussion Purposes Only


Li/CF_x-MnO₂
Radiation cell
discharge
performance at
250 mA, 21 °C


Radiation does not appear to impact capacity or energy



Pre-Decisional Information -- For Planning and Discussion Purposes Only

OCV and Impedance change drastically for Li/CF_x D-cell after 10 MRad






Pre-Decisional Information -- For Planning and Discussion Purposes Only

Discharge 2% of capacity at 250 mA, 21 °C to remove any film grown during radiation


Initial voltage drop affected by time after radiation



Pre-Decisional Information -- For Planning and Discussion Purposes Only

Quantifying EIS changes over time for Li/CF_x cells






Pre-Decisional Information -- For Planning and Discussion Purposes Only


5 mV excitation voltage

Measured at 21 °C

2% discharge effects on EIS and OCV








Pre-Decisional Information -- For Planning and Discussion Purposes Only

Total capacity and specific energy for Li/CF_X D-cells drops by ~2% after radiation




	Capacity (Ah)	Specific Energy (Wh/kg)
Non-irradiated average:	18.64	682
10 MRad average:	18.28	667
Drop:	1.94%	2.23%



Build 3-electrode cells to understand effects on individual electrodes






Experimental Design

- Li/CF_X-MnO₂ cells typically use LiClO₄ as an electrolyte salt
- Li/CF_X cells typically use LiBF₄ as an electrolyte salt
- Two cells with 0.75 M LiBF₄ in PC+DME (3:7 by vol.)
- Two cells with 0.75 M LiClO₄ in PC+DME (3:7 by vol.)
- Subject one of each to 10 MRad
- Keep one of each for control


Film on cathode of Li/CF_X cell with LiClO₄ salt appears unaffected after 10 MRad





Film on anode of Li/CF_X cell with LiClO₄ salt appears unaffected after 10 MRad





BF₄ salt leads to significant increase in "film" resistance on anode

Pre-Decisional Information -- For Planning and Discussion Purposes Only



Conclusions

- Li/CF_X cells provide the highest available specific energy
- Degradation of the cell has been observed in Li/CF_x D-cells
 - Increased "film" resistance
 - Increased low frequency resistance
 - Increased cell OCV
 - Lower energy
 - Lower capacity
- "Film" resistance grows in 3-electrode cells with LiBF₄ salt
 - Both anode and cathode are affected
- "Film" resistance remains constant in 3-electrode cells with LiClO₄ salt
 - Hope to incorporate other salts into prototype Li/CF_X D-cells



Acknowledgements

The work described here was carried out at the Jet Propulsion Laboratory, California Institute of Technology, under contract with the National Aeronautics and Space Administration (NASA), and was supported by the Planetary Science Division.