




***In Situ* Polysulfide Detection in Lithium Sulfur Batteries**

John-Paul Jones, Simon C. Jones, Frederick C. Krause,
Jasmina Pasalic and Ratnakumar Bugga


Jet Propulsion Laboratory, California Institute of
Technology

4800 Oak Grove Drive, Pasadena, CA 91109

© 2018 California Institute of Technology. Government
sponsorship acknowledged




Jet Propulsion Laboratory
California Institute of Technology



Outline

- Background
 - Modified cathodes
 - Modified separators
- Approach
 - 4 electrode cell design
- Cyclic voltammetry results
 - Sulfur baseline
 - Modified cathodes
 - Modified separators
- Conclusions
- Future work

Polysulfide species during discharge



- Intermediate discharge products (polysulfide species) are soluble in most organic electrolyte systems
- Polysulfide species can react with anode
- Essential to extract full capacity from cathode



Fig. 1. A typical discharge and charge voltage profile of the first cycle of Li/S cells.

S.S. Zhang, *J. Power Sources*. 231 (2013) 153–162.

doi:10.1016/j.jpowsour.2012.12.102



Previous work with high loading metal sulfide blended cathodes

Replacing some carbon black with MoS_2 or TiS_2 allowed increased cathode loading while maintaining high capacity and stable performance over time




R. V. Bugga et al., *J. Electrochem. Soc.* 164 (2017) A265–A276.
doi:10.1149/2.0941702jes

TiS₂ participates in cathode reactions, but MoS₂ doesn't by XRD analysis





Separators also play major role in Li/S performance

- Hypothesis that MoS_2 doesn't participate electrochemically motivated study on ceramic additives to separator
- Significant effects on discharge capacity and cycle life
- **Are the ceramic particles chemically interacting with dissolved polysulfide species?**



4-Electrode cell design




- Li/S prismatic cell with Li-metal reference and Pt wire working
- Li anode (2.5 x 2.5 cm), S cathode (2.5 x 2.5 cm) and Li ref. (0.5 x 1.0 cm) individually separated
- 6.35 mm (1/4") thick PE shim provides stack pressure and reduces electrolyte volume
- Pt wire with heat shrink tubing to isolate 0.8 cm² area
- Allows independent control of Pt wire in reference to Li-metal reference
- Li-anode used as counter
- 3 mL electrolyte volume




CV on Pt wire at stages during 1st discharge

- Standard sulfur cell
 - 3.6 mg/cm² S content
 - Tonen-Setela 20 μ m separator
 - 3 mL 1.0 M LiTFSI DME+DOL (95:5 vol.) + 0.2 M LiNO₃
- Discharged at 0.75 mA/cm² (4.7 mA)
- Discharge paused every 10 % of theoretical capacity (2.23 mAh, based on 1000 mAh/g sulfur cathode)
- CV scan at 10 mV/s from OCV to 3.5 V, down to 1.3 V and back to OCV twice
- CV1 is initial scan
- CV7 is after 1.8 V cutoff voltage reached
- Reductive peak at \sim 1.4 V may be due to LiNO₃¹




¹Zhang, S. S. *Electrochim. Acta* **2012**, 70, 344

Discharge profile and maximum current in oxidative sweep




- Maximum current taken from CV
- Oxidizing S_x^{2-} species likely more repeatable than reducing oxidized product
- Full peak not resolved → difficult to integrate
- Peak height correlates with state of charge for first discharge




Comparison with Sulfur-MoS₂ composite cathode


Standard sulfur cathode with Tonen-Setela separator



Sulfur-MoS₂ cathode* with Tonen-Setela separator




*capacity steps not adjusted for higher loading cathode





Comparison with ceramic Al_2O_3 -coated separator

Standard sulfur cathode with Tonen-Setela separator




Standard sulfur cathode with Asahi Al_2O_3 -coated separator






Comparison with sulfur-MoS₂ cathode and ceramic Al₂O₃-coated separator

Standard sulfur cathode with Tonen-Setela separator




Sulfur-MoS₂ cathode* with Asahi Al₂O₃-coated separator




*capacity steps not adjusted for higher loading cathode

Maximum oxidative current comparison

- Baseline sulfur cathode with Tonen separator produces highest concentration of sulfide species in short time
- Adding either Al_2O_3 or AlF_3 to separator reduces polysulfide species in electrolyte
- Adding MoS_2 to cathode reduces polysulfide concentration
- Adding both MoS_2 to cathode and Al_2O_3 to separator slows polysulfide migration
- Concentrated "7M" LiTFSI in DME+DOL (50:50)¹ virtually eliminates polysulfide content in electrolyte




¹L. Suo et al., *Nat. Commun.* 4 (2013) 1481. doi:10.1038/ncomms2513




Sulfur-specific maximum oxidative current comparison


- Plotted per gram of sulfur in cathode
- MoS_2 -containing cathodes produce significantly lower polysulfide concentrations on a specific basis than pure sulfur cathodes



CV scans in concentrated electrolyte




- "7M" LiTFSI in DME+DOL (1:1) electrolyte
- Cell operated at 40 °C
- Sulfur cathode
- Tonen separator
- No appreciable sulfur in electrolyte during discharge




Conclusions

- 4-electrode prismatic glass cell indicates that polysulfide species start to accumulate during 2nd stage of 1st discharge
- Modifications to cathode and/or separator can affect concentration of polysulfide species in electrolyte
 - Cell with MoS₂-modified cathode reached equilibrium condition during 2nd voltage plateau
- Although there is some reduction in soluble polysulfide species when modified cathode or separator are used, they have not been fully suppressed
 - Does not explain improved performance
- High concentration “7M” electrolyte showed no peak attributable to polysulfide species




Ongoing and Future Work

- Develop method to automate CV and discharge measurements
 - Increase number of CV scans during discharge
 - Run CV scans during charge
 - Decrease downtime for cell
- Develop better sealing technique to prolong cell life
 - Study effect of cycling on polysulfide concentration
- Apply method to new cathode/separator modifications
- Investigate cause for improved capacity and cycle life from modified cathodes and separators




Acknowledgements

This work was carried out at the Jet Propulsion Laboratory, California Institute of Technology, under contract with the National Aeronautics and Space Administration. The authors acknowledge the funding support of Army (CERDEC).




Backup

Growth of sulfide peak after cycling



- Sulfide concentration grows with cycling in the case of S-MoS₂
- Increases to approximately same level as pure sulfur cathode with Tonen after 10 cycles
- Indicates that sulfide species eventually make it into electrolyte

Rapid capacity fade after first cycle



- Unclear if sharp drop in capacity is due to CV studies or cell design
- Sealing is not as good as coin cell

