

*42nd COSPAR Scientific Assembly 2018 July 17, 2018*

# **INVESTIGATION OF GAMMA IRRADIATION AS A PLANETARY PROTECTION MICROBIAL REDUCTION PROCESS**

PI: Laura Newlin  
Co-I: Fei Chen  
Zachary Dean  
Raffaele Gradini  
Charlotte Spry  
Kristina Stott

**Jet Propulsion Laboratory/California Institute of Technology  
Pasadena, CA**

# Agenda

- Background Information
  - Planetary Protection (PP)
  - What is Gamma Irradiation?
  - Need for Gamma Irradiation
- Methods
- Results
- Conclusion and Recommended Future Investigations
- Acknowledgements

# Background Information: Planetary Protection

## What is Planetary Protection (PP)?

- To protect the planets (and science) by preserving them as a target of biological exploration
  - Includes forward (outbound) and backward (Earth return) missions
  - Prevents false positive findings by life detection missions

## Meeting the Biological Cleanliness requirements for Mars and Icy satellites:

- In order to meet the PP requirements
  - Spacecraft components need to be cleaned / microbially reduced and protected from recontamination
  - Biological cleanliness is a key / driving requirement throughout the entire lifecycle of the project—from Pre-Phase A until spacecraft disposal.


# Background Information: Planetary Protection

- Need:
  - Heat Microbial Reduction (HMR) is the primary microbial reduction method
  - Gamma provides penetrating microbial reduction alternative for hardware sensitive to HMR:
    - Antennas
    - Batteries
    - Reaction wheel lubricants
    - Etc.




# Background Information: Gamma Irradiation

- Alpha particles are larger—2 protons and 2 neutrons (charged helium atom)
- Beta particles are electrons
  - Also break bonds (ionizing)
  - Less penetrative than gamma, more than alpha
- Gamma is photon energy
  - Same as light energy (UV radiation, etc.), but gamma rays carry much more energy
    - Unlike UV, gamma breaks molecular bonds




# Background Information: Gamma Irradiation

- Typically carry energy > 100keV
- Important:
  - Typical gamma sources do not cause hardware to become radioactive
    - The energy is too low



# Background Information: Need



Europa as seen from  
Galileo



## Heat microbial reduction (HMR):

- NASA PP approved protocol
- Can treat bulk and surfaces of hardware



## Vapor hydrogen peroxide (VHP):

- NASA PP approved protocol (use less common than HMR)
- Can only treat hardware surfaces



## Gamma Irradiation ( $\lambda$ ):

- NASA PP protocol not yet established
- Can treat bulk and surfaces of hardware
- Useful for Jovian missions, for hardware not compatible with heat (chemical reactions, etc.), and when more microbial reduction is needed than HMR can provide alone

# Background Information: Need

| Advantages                         | Disadvantages                       |
|------------------------------------|-------------------------------------|
| Low Temperature                    | Not Validated                       |
| Predictable and Repeatable         | Cost                                |
| No Radiation Byproduct or Residual | Polymers & glasses can be affected* |
| No Further Process Required        | Radioactive source                  |
| Volumetric                         |                                     |
| Time                               |                                     |

\* Polymers which are radiation stable are very expensive



# Methods


- Selected organisms based on the following criteria:
  - Known radiation resistance
  - Desiccation resistance
  - Heat resistance
  - Available in the JPL PP archive
- Both spore formers and non-spore formers were selected:
  - Deinococcus radiodurans* (most radiation resistant organism known)
  - Bacillus pumilus* (gamma indicator organism)
  - Bacillus atrophaeus*, ATCC 29669 (heat indicator organisms)
  - Geobacillus stearothermophilus* (VHP indicator organism)
- Overall goal:
  - Determine dose to eliminate extremophiles, assess *D*-values






# Methods

- High-level procedure:



Dry organisms on plate



Expose to gamma




Plate and observe growth


# Results

- Preliminary results (curves end where no growth occurred)

## Vegetative Survival Curve




## Spore Survival Curve



# Results


- Preliminary results (no growth at 4, 6 Mrad)
  - *D. radiodurans* is the most radiation resistant organism known





# Results

## Literature Study on Results (courtesy Reuhle, M. & Park, H.):



# Conclusion and Recommended Future Investigations

## Conclusion

- Gamma Irradiation is a viable protocol that is useful for microbial reduction
  - Particularly in situations where HMR is not possible

## Recommended Future Investigations

- Materials compatibility
  - Only requires a dosimeter (no organisms)
  - Effective measurement of maximum dose that hardware can take
- Determine exposure needed for reduction in bulk materials
- Establish NASA PP approved protocol for gamma irradiation as a sterilization modality

# Acknowledgements

- The research was carried out at the Jet Propulsion Laboratory, California Institute of Technology
- The JPL team contributing to this study were: Zach Dean, Laura Newlin, Kristina Stott, Fei Chen, Raffaele Gradini, and Charlotte Spry.




**Jet Propulsion Laboratory**  
California Institute of Technology

---

# Back-up Slides

# Radiation Dosimeters (cont'd)




- Used for chamber and dose-validation
- Inexpensive: \$1236 per 1000
- 0.5 - 5 Mrad dose range (matches our required range)
- Easy to use:
  - Spectrometer measurement
  - Small, can be attached to H/W easily
- Quality-controlled:
  - Each batch is calibrated (and shipped with calibration curve) at the National Physical Laboratory (Teddington, England)
    - Curve (bottom-left)
- Used by Steris

# Radiation Dosimeters (cont'd)



Dose distribution within a Co-60 irradiator (each is unique)




Dosimeters placed in 3D configuration on hardware

- Positioned around hardware to determine actual maximum dose received during sterilization
  - To compare this number to the sterilization dose required
- Uniformity of dose distribution (dose-mapping) on hardware also measured
  - Dose Uniformity Ratio =  $\frac{\text{Max Measured Dose}}{\text{Min Measured Dose}}$ 
    - Always > 1, but should not increase over 2
  - More 3-D resolution needed for more complex hardware

# Radiation Dosimeters (cont'd)



Dose distribution within a Co-60 irradiator (each is unique)




Dosimeters placed in 3D configuration on hardware

- Reference dose-mapping can be done with surrogate H/W (reference hardware)
  - Done to simulate product placement in packaging (bagging, etc.)
  - Prevents recontamination retrieving dosimeters after H/W exposure in gamma
  - However, must be in triplicate
- New mapping should be done when irradiator rack is changed
- Plan for gamma materials testing this summer will use surrogate H/W
  - No organisms




# Down-select Experiment (cont'd)

## *D-Value – Deinococcus radiodurans*



# Down-select Experiment (cont'd)

## *D-Value – Acinetobacter radioresistens WC-A-157*




# Down-select Experiment (cont'd)

## *D-Value – Staphylococcus epidermidis strain F71028*




# Down-select Experiment (cont'd)

## *D*-Value – *Bacillus atrophaeus* (vegetative cells)




# Down-select Experiment (cont'd)

## *D-Value – Bacillus pumilus* (vegetative cells)



# Down-select Experiment (cont'd)

## D-Value – ATCC 29669 (vegetative cells)



# Down-select Experiment (cont'd)

## *D-Value – Geobacillus stearothermophilus* (vegetative cells)

