



Autonomous Target Selection and Observation for Curiosity and Mars 2020 Rovers

Vandi Verma

NASA Jet Propulsion Laboratory, California Institute of Technology

4/27/19

Southern California Robotics Symposium

Copyright 2019 California Institute of Technology. Government sponsorship acknowledged.



AEGIS & Autonomous Robotic Arm Positioning

AEGIS

Tara Estlin

Daniel Gaines

Raymond Francis

Gary Doran

Vandi Verma

Curiosity ChemCam

Roger Wiens

Steven Johnstone

Suzi Montaño

Olivier Gasnault

Laurent Peret

Eric Lorigny

Diana Blaney

Jens Frydenvang

M2020 Autonomous Arm Positioning

Jeffrey Biesiadecki

Joseph Carsten

Vandi Verma

Texture Cam

David Thompson

Curiosity AEGIS Operations


Deb Chattopadhyay

Betina Pavri

AEGIS: Autonomous Targeting


Autonomous Exploration for Gathering Increased Science

- An **intelligent software** system
- Running since 2016 **on-board** the *Curiosity* rover. Will be on *Mars 2020* rover.
- **Autonomously chooses science targets** and measures them with the ChemCam laser spectrometer instrument
- Favours targets based on **scientists' preferences**
- Regularly, reliably interprets **complex natural scenes**
- Has **consistently performed well** even in unexplored terrain






ChemCam Instrument

- Chemistry and Camera (Chemcam)
 - Laser-Induced Breakdown Spectrometer (LIBS). Rasters typically have a spacing of 1 mrad.
 - Remote Micro-Imager (RMI). Narrow-field (20 mrad diameter).
- Gives geochemical composition of rock targets at ranges up to 7 metres
- Over 440,000 measurements on 1500 targets on Mars since 2012




ChemCam Targeting

- Targets selected by specialists on Earth, inspecting images returned from Mars
- NavCam, sometimes MastCam or MAHLI
- Choose suitable science targets at each location
- Ensure proper focus and raster size/shape



Autonomous Robotic Arm Positioning

Improved arm positioning accuracy without additional ground-in-the-loop cycles
Acquire high standoff Watson images after a drive (without ground-in-the-loop)
Downlinked as part of critical telemetry for planning on subsequent sol




Sol 1241




Iteratively inchworm closer for highest accuracy

On M2020 we would like to do the same without ground in the loop




Curiosity planning

A (simplified) typical day on Mars




Curiosity planning

A (simplified) typical day on Mars




Curiosity planning

A (simplified) typical day on Mars




Curiosity planning

A (simplified) typical day on Mars




Curiosity planning

A (simplified) typical day on Mars




Curiosity planning

A (simplified) typical day on Mars



Curiosity planning

A (simplified) typical day on Mars



Pointing challenges

- Pointing precision is a challenge!
 - Backlash
 - Stereo accuracy & registration
 - Rover shifting/settling
 - Thermal expansion
- Missing targets
 - Try again or lose the target

target=White_Cliffs
1x5 Raster
distance=2.80m
nimages=2
npoints=5
sol=771




Target: White_Cliffs

Range: 2.8

Length: 1.3 cm


Width: ~2 mm




Initial ChemCam raster
1.4 mrad spacing

Pointing challenges

- Pointing precision is a challenge!
 - Backlash
 - Stereo accuracy & registration
 - Rover shifting/settling
 - Thermal expansion
- Missing targets
 - Try again or lose the target



target=White_Cliffs
1x5 Raster
distance=2.80m
nimages=2
npoints=5
sol=771



target=White_Cliffs_2
1x5 Raster
sol=773
nimages=2
npoints=5



AEGIS Intelligent Targeting System

“Automated Exploration for Gathering Increased Science”


AEGIS was first flown on MER Opportunity in 2010

- Autonomous target selection for PanCam (mid- or post-drive)


Now in use for ChemCam on Curiosity, in two roles

- Autonomous target selection in NavCam images
- Autonomous pointing refinement in RMI images


NavCam



RMI




AEGIS Target Detection using Rockster



Target Property Evaluation

Size

- Number of pixels
- 3D estimate (from stereo)
- Ellipse semi-major axis
- Ellipse semi-minor axis



Ellipse fit example

Position

- Distance from rover
- Inscribed circle x, y
- Site x, y, z
- Site az, el



Inscribed circle example

Target Property Evaluation

Intensity

- Mean
- Variance

Light

Dark



Shape

- Eccentricity
- Ellipse fit error
- Ruggedness
- Orientation





Rounded

Angular

Target Prioritization

- Scientists can prioritize different property values
 - Single or combinations
 - e.g., prefer large, high albedo rocks
- Property setting is done at command sequencing
- Can be easily changed as rover enters different terrain areas
- Can support specific mission campaigns
 - E.g. cobble finder, outcrop finder



Detected rock of round shape



Detected rock of large size


ChemCam Collision Safety

- Don't shoot the rover!
- AEGIS must recognize and reject unsafe pointings
- Onboard model of rover articulation



Onboard Process


Image pointing determined by ground.



Navcam or RMI acquisition

Target detection

Detection of rock candidates in Navcam image.




Quantification of key target properties such as intensity, size, shape, and distance from rover.



Target feature extraction

Target filtering

Ops can filter targets based on size, distance, etc.



Ops can prioritize important properties for each run

Target prioritization

Top score for large size

Set VTT frame to target position




CCAM raster acquired using VTT frame

Can repeat for multiple targets






Acquire ChemCam LIBS raster of target (size and direction pre-specified by ground)




Results: Pointing refinement


- Sol 1424 & Sol 1463
- Small, bright features
 - RMI FOV: 20 mrad \emptyset
- Initial (ground-selected) pointing missed target
- AEGIS corrected pointing and hit the target
- Saved observation – a manual retargeting second attempt would have been necessary. Not possible if rover were to drive in that plan




Results: Target selection




Results: Target selection




Sol 1400



Sol 1417




Sol 1481



Sol 1636


More data from ChemCam



- Significant increase in rate of data return from ChemCam
- AEGIS rollout to science team on sol 1343


Mars 2020 planning

A (simplified) typical day on Mars




Terrain Height Map

Fine resolution terrain map
256x256 cells, mapping 2.0x2.0 m





4. Then, build medium resolution map from max Z of cells in the fine resolution height/occlusion map

Medium resolution terrain map
16x16 cells, mapping 2.0x2.0 m






5. Finally, repeat to build coarse resolution map

Coarse resolution terrain map
2x2 cells, mapping 2.0x2.0 m



Mars Yard Test Cases





Flight Infusion Challenges

- 133 MHz RAD750 flight processor
- Limited onboard memory
 - 256 MB of DRAM, 128 MB of RAM
 - AEGIS limited to 16MB
 - Autonomous arm positioning limited to 16MB
- Safety constraints
 - Sun-Safety
 - Collision
- Operations complexity
 - New commands need to be intuitive for operators to use
 - Must add operational value over traditional commanding




Autonomous Target Selection and Observation for Curiosity and Mars 2020 Rovers

Vandi Verma

NASA Jet Propulsion Laboratory, California Institute of Technology
vandi@jpl.nasa.gov

- **Sol 1400: AEGIS selects the only clear patch of bedrock in the field of view.**



Sol 1662: Finding unusual chemistry

Rock was visually unremarkable

Points 5 & 8 had notable chemistry for the local bedrock, with certain elemental abundances unusual

Team spent a targeted observation revisiting this spot.




Sol 1673: Collect all 3

Upper, smooth material

Brighter vein

Lower, rough material


AEGIS had already measured the upper unit, allowing a complete survey with only 2 targeted measurements



Sol 1673: Collect all 3

- 1) Upper, smooth material
- 2) Brighter vein
- 3) Lower, rough material


AEGIS had already measured the upper unit, allowing a complete survey with only 2 targeted measurements



Sol 1673: Collect all 3

- 1) Upper, smooth material
- 2) Brighter vein
- 3) Lower, rough material

AEGIS had already measured the upper unit, allowing a complete survey with only 2 targeted measurements



Sol 1612: Highest chlorine

Highest concentration of chlorine ever measured by ChemCam on Mars

(So high it strains the calibration)







Figure from Pierre-Yves Meslin

Lighting robustness

AEGIS autonomous targeting performs well across the **range of lighting conditions** we've seen

- Solar elevation and angle (time of day)
- Direction of lighting relative to the rover (and FOV)





- A suite of software and algorithms for automatic classification of geologic surfaces
- Maps surfaces with texture channels which signify statistical patterns of image pixels
- To create a set of classifiers, uses a decision forest. Trees are created by training on a subset of pixels.


Run durations for NavCam



Run times on Curiosity flight RCE
for
AEGIS_FIND_TARGETS_NAVCAM

Roughly linear with number of
targets found (90 s + 1.4 s per
target)

- Current timeout is set to 600 s
- Includes a couple of actions
not accounted here
- Should not reduce timeout
much, if at all

Run times on Curiosity flight RCE
for AEGIS_FIND_TARGETS_RMI
are about 95-105 seconds





- A suite of software and algorithms for automatic classification of geologic surfaces
- Maps surfaces with texture channels which signify statistical patterns of image pixels

David R Thompson


Jet Propulsion Laboratory, California Institute of Technology

david.r.thompson@jpl.nasa.gov


TextureCam is funded by the NASA Astrobiology Science and Technology Instrument Development program (NNH10ZDA001N-ASTID). This presentation copyright 2013 California Institute of Technology. All Rights Reserved.

Other TextureCam applications

Layer detection, mapping



A “software sieve” for particle sizes



K. Wagstaff, D. R. Thompson, W. Abbey, A. Allwood, D. Bekker, C. Cabrol., T. Fuchs, K. Ortega. D.
Geophysical Research Letters 2013 (accepted, to appear)

Related Work in Rover Autonomous Science

Onboard Spacecraft Autonomy for Science:

- MER rover atmospheric event detectors (Castano, 2008)
 - Only downlink images that contain dust-devils or clouds

Mission Ground Planning Tools:

- MAPGEN MER rover automated planner (Bresina, 2005)
 - Used by MER operators for science activity planning
- MEXAR automated planner for ESA Mars Express (Cesta, 2007)
 - Used by Mars Express operators for data downlink planning

Image processing for geological features

- CMU Life in the Atacama (Smith, Wettergreen 2008)
- ESA ExoMars onboard analysis and planning (Pugh, 2010)

Image categorization and segmentation using decision trees (Shotton 2008; Moosman 2006)

Research on automated planning for robotic operations

- LAAS-CNRS autonomous robotic systems (Ingrand, 2007)
- ARC robotic site survey (Pederson, 2001) (Fong, 2008)
- ESA ExoMars onboard analysis and planning (Woods, 2009)



MER
dust-devil
detection



ESA
ExoMars
rover




ARC site
survey

AEGIS Target Detection using TextureCam

Maps surfaces with texture channels that signify statistical patterns of image pixels

A. In advance


Build statistical models of geologic surface appearance using decision trees




Original image: NASA/JPL/Caltech/Cornell

B. Online

Classify new image pixels



Analyze local patterns



Surface classification for new scene