

ASEC 2019

Applied Space Environments Conference

May 12–17, 2019 | Los Angeles, California

Comparison of Total Ionizing Doses from Representative Space Radiation Shielding Analysis Tools

Bongim Jun*, Luz Maria Martinez Sierra, Brian X. Zhu, and Insoo Jun

Copyright 2019, California Institute of Technology. Government Sponsorship Acknowledged.



Outline



- Motivation
- Introduction to Transport Tools Evaluated in This Study
- NOVICE Validation Against MCNP
 - Why do you believe that NOVICE is “conservative”
 - Verification that NOVICE is being used properly
- FASTRAD Validation Against NOVICE
 - Shielding Geometries and Mission Environment
 - Simple Geometry (Shell and Box)
 - Cylindrical Vault Geometry
 - Complex Geometries
- Geant4 Validation Against MCNP
 - Forward Monte Carlo Results from Geant4, FASTRAD, and MCNP
- Conclusion



Motivation

- Space radiation is a key design consideration for any space mission
- Spacecraft should be designed to survive exposure to expected radiation environment for a mission
- Multiple commercial tools are available to predict ionizing and displacement damage doses, but they often produce differing results beyond stated errors
- Good understanding of dose predictability of transport tools is critical for shielding design optimization





Introduction to Transport Codes

FASTRAD

- **Purpose:** system-level TID calculations and shielding analysis for parts/materials
- **Method:** **Ray tracing** (Input requirement: Dose Depth curves from e.g. Shieldose, NOVICE)
- **CAD input:** STEP, IGES, GDML format
- **Run Time:** Quick running time (minutes to hours)

NOVICE

- **Purpose:** system-level TID calculations and shielding analysis for parts/materials
- **Method:** **Adjoint Monte Carlo method** (reverse Monte Carlo, RMC)
- **CAD input:** VRML format
- **Run Time:** Moderate running time (hours to days)

Geant4

- **Purpose:** detailed treatment of particle interaction physics for part/material/detector response simulation.
- **Method:** **Forward Monte Carlo (FMC) particle transport** with accurate physics and data bases for nuclear interactions
- **CAD input:** CSG, GDML format
- **Run Time:** Moderate running time (hours to days)

MCNPX

- **Purpose:** detailed treatment of particle interaction physics for part/material/detector response simulation.
- **Method:** **Forward Monte Carlo particle transport** with accurate physics and data bases for nuclear interactions
- **CAD input:** No direct transport format available. Not for S/C level analysis
- **Run Time:** Long running time (days)

LONGER Running Time





NOVICE Validation: [1/2]

Is MCNP Acceptable?

- MCNP Analysis:

- Forward Monte Carlo particle transport with accurate physics and data bases for nuclear interactions
- MCNP's dose predictability has been demonstrated through numerous ground experiments with wide ranges of materials and energies




- Insoo Jun, IEEE Transactions on Nuclear Science 2003



- MCNP simulation results show good agreement with experiment results

- TID comparison between MCNP and NOVICE
 - MCNPX
 - NOVICE 2006, adjoint b=4

Aluminum: 1 ~ 30 g/cm²



Tungsten: 1 ~ 30 g/cm²



-M. Cherng et al., *Nuclear Instruments and Methods in Physics Research* 2007

- *NOVICE results show good agreement with MCNP results*





Outline


- Motivation
- Introduction to Transport Tools Evaluated in This Study
- NOVICE Validation Against MCNP
 - Why do you believe that NOVICE is “conservative” when used properly
 - Verification that NOVICE is being used properly
- **FASTRAD Validation against NOVICE**
 - **Shielding Geometries and Mission Environment**
 - **Simple Geometry (Shell and Box)**
 - **Cylindrical Vault Geometry**
 - Complex Geometries
- Geant4 Validation against MCNP
 - Forward Monte Carlo Results from Geant4, FASTRAD, and MCNP
- Conclusion





Mission Environment: Radiation Spectrum

A Jovian Mission




- Intense radiation environment, dominated by trapped electrons
- All fluence spectra are input parameters in Monte Carlo code based tools




Ionizing Dose Depth Curves

Aluminum

Spherical Shell Shielding




Solid Sphere Shielding




- NOVICE adjoint k-option was used for a series of Al shielding thicknesses
- FASTRAD uses NOVICE outputs as inputs in ray tracing analysis


Shield Geometries Used in This Study



S-1




S-2




S-3

Spherical Shell


1. Material
 - S-1: Aluminum
 - S-2: Tantalum/Al
 - S-3: Ta
2. Dimension
 - Radius: 5 cm
 - Thickness: 0.05 ~ 30 g/cm²



B-1




B-2




B-3

Cubic Box


1. Material
 - B-1: Aluminum
 - B-2: Tantalum/Al
 - B-3: Ta
2. Dimension
 - Length: 10 cm
 - Thickness: 0.05 ~ 30 g/cm²



C-1



C-2



C-3

Cylindrical vault

1. Material
 - C-1: Aluminum
 - C-2: PCB/Ta/Aluminum
 - C-3: Ta
2. Dimension
 - Cylinder (RxH)=10cm x30cm
 - Box/slab length= 10cm
 - Thickness: 0.25 cm

Shield Materials

- Aluminum ($d=2.7 \text{ g/cm}^3$)
- Tantalum ($d=16.6 \text{ g/cm}^3$)
- Aluminum/Tantalum


Transport Codes

- MCNPX, MCNP6 FMC
- FASTRAD 3.8.10
 - ray tracing, RMC, FMC
- NOVICE 2017, adjoint b=8
- Geant4, FMC
 - G4EmLivermorePhysics
 - G4HadronPhysicsQGSP_BIC_HP

- Point detector for ray tracing analysis
- Volume detector for Monte Carlo analysis
- Run errors of all remained less than 5%




B-1




Al Thickness:
0.05 -30 g/cm²

MCNP vs. NOVICE




NOVICE vs. FASTRAD



- NOVICE RMC, JPL heritage transport analysis tool, is conservative
- FASTRAD ray tracing over predicts doses in comparison with NOVICE
 - The discrepancy increases when high-Z material is incorporated (due to single material dose depth curves)
 - Shell shielding option shows better agreement with NOVICE for typical shielding thicknesses
- FASTRAD RMC predicts higher TID but the difference remains similar for high-Z shieldings




C-series




All aluminum
Al/Ta/PCB
All tantalum

MCNP vs. NOVICE



NOVICE vs. FASTRAD




- NOVICE RMC is conservative except high-Z, thick shielding geometry
- FASTRAD ray tracing predicts higher than NOVICE
 - Shell shielding option shows better agreement with NOVICE, especially for aluminum shielding geometry
- FASTRAD RMC predicts higher TID, especially when high-Z element is incorporated




Outline

- Motivation
- Introduction to Transport Tools Evaluated in This Study
- NOVICE Validation Against MCNP
 - Why do you believe that NOVICE is “conservative” when used properly
 - Verification that NOVICE is being used properly
- **FASTRAD Validation against NOVICE**
 - Shielding Geometries and Mission Environment
 - Simple Geometry (Shell and Box)
 - Cylindrical Vault Geometry
 - **Complex Geometries**
- Geant4 Validation against MCNP
 - Forward Monte Carlo Results from Geant4, FASTRAD, and MCNP
- Conclusion

A Jovian Mission Spacecraft Model




- Spacecraft model used in this study is early version released during design optimization phase





Electronics and Instrument CAD Models

-w/ actual materials including high-Z local shields




- 311 detector points are surveyed for TID



TID Comparison: Complex Geometries [1/2]

- *FASTRAD* vs. *NOVICE*

From Deeply Shielded Parts




- FASTRAD ray tracing results with shell dose depth curves (DDC) reported in ERD are conservative within run errors
- FASTRAD ray tracing results for solid sphere DDC with slant path calculation are sometimes lower, sometimes higher, than NOVICE results
- FASTRAD RMC results show better agreement with NOVICE for complex geometry cases except heavily shielded geometry giving-TID less than 20 krad



Total Doses from Actual Geometries [2/2]

-*FASTRAD* vs. *NOVICE*

Marginally to Weakly Shielded Parts



- FASTRAD ray tracing method with shell dose depth curves (DDC) predicts doses similar to, or above, NOVICE dose
- FASTRAD ray tracing with solid sphere DDC/slant path option can under-predict doses
- FASTRAD RMC results show better agreement with NOVICE for complex geometry cases





Outline

- Motivation
- Introduction to Transport Tools Evaluated in This Study
- NOVICE Validation Against MCNP
 - Why do you believe that NOVICE is “conservative” when used properly
 - Verification that NOVICE is being used properly
- FASTRAD Validation against NOVICE
 - Shielding Geometries and Mission Environment
 - Simple Geometry (Shell and Box)
 - Cylindrical Vault Geometry
 - Complex Geometries
- **Geant4 Validation against MCNP**
 - **Forward Monte Carlo Results from Geant4, FASTRAD, and MCNP**
- **Conclusion**






TID Comparison Result [1/2]

Geant4/FASTRAD_FMC vs. MCNP




Al Thickness:
0.05 -30 g/cm²





- FASTRAD FMC predicts higher TID than MCNP for all geometries
- Geant4 under predicts doses of shells and boxes as thickness increases
- Geant4 under predicts doses of cylinder vaults for all material combinations

Cut length




Al Thickness:
 3 g/cm^2



Al Thickness:
 $1 - 5 \text{ g/cm}^2$

Energy Spectrum Input Format



- Energy deposition range cut to be optimized for Geant4 runs
 - With shorter cutlength, TID can be increased by ~10% from the used value of 10 um
- Radiation particle spectrum input format change from integral to BIN affects dose significantly
- It can be further improved by using same physics options for both Geant4 and FASTRAD FMC



Conclusion

- MCNP accepted as foundation
- Novice conservative in comparison with MCNP
 - Except high-Z element / thick shielding combination
- FASTRAD ray tracing favorable for preliminary assessment
- FASTRAD Monte Carlo conservative in comparison with NOVICE
- Geant4 can be comparable with MCNP with optimized run parameters
 - Cut-length, radiation spectrum input format, and etc





Jet Propulsion Laboratory
California Institute of Technology

THANK YOU!


Copyright 2019, California Institute of Technology. Government Sponsorship Acknowledged.




BACKUPs

1. Geometry/Material



Aluminum: 1 ~ 30 g/cm²



Tungsten: 1 ~ 30 g/cm²



2. TID Results from Multiple NOVICE version/adjoint



3. Discussion

- Outliers from b=8 adjoint options of 2006 and 2015 are due to double counts of secondary electrons in the final dose and it was discovered through NOVICE new version validation

- JPL's current baseline for Europa Clipper TID analysis is NOVICE 2017 adjoint b=8 option
- JPL works closely with the vendor to validate new revisions, prior to insertion to official transport analysis

